

TASK SEATING



Chesapeake

(Without headrest - shown)

This one of a kind chair is working to revolutionize the task chair industry. Its weight-sensitive recline and synchronously adjustable armrests set new standards for task chair performance and functionality. It works to keep the sitter exceptionally comfortable while also lowering the risk of long-term injury. The intelligent counter-balance recline mechanism provides the right amount of support throughout the full range of recline. The back rest automatically adjusts to the changing needs of the spine and provides additional lumbar support when needed.



MARYLAND CORRECTIONAL ENTERPRISES

For more information:
Contact Customer Service 410-540-5454
www.mce.md.gov

CHESAPEAKE CHAIR FEATURES

Synchronous Armrests

To raise, gently pull upward on the armrests to desired position. To lower, rotate wrist toward you to disengage. Lower to desired position.

Headrest

Grasp headrest with both hands and move to desired position. The dynamic, position-sensitive headrest cradles your head and neck as you recline, and automatically moves out of the way when you sit upright.

Seat Depth

Lift up on lever located under front edge of seat. Slide seat to a position that when you're sitting with your back fully against the backrest, there are two to four inches of clearance between the front edge of the seat and the back of your knee. Release lever.

Seat Height

Lift up on the lever located under the right side of the seat cushion and position chair to a comfortable height. Release lever.

Backrest/Lumbar Support Height

While seated, grasp the lower corners of the backrest with both hands. Squeeze handle located on the right with fingertips and move backrest to most comfortable height.



CHESAPEAKE

This one of a kind chair is working to revolutionize the task chair industry. Its weight-sensitive recline and synchronously adjustable armrests set new standards for task chair performance and functionality. It works to keep the sitter exceptionally comfortable while also lowering the risk of longterm injury. The intelligent counter-balance recline mechanism provides the right amount of support throughout the full range of recline. The back rest automatically adjusts to the changing needs of the spine and provides additional lumbar support when needed.

Dimensions

High Back Overall	26 3/4"W x 19"D x 53"H
Low Back Overall	26 3/4"W x 19"D x 51"H
Back	19"W x 18 - 21"H
Seat	17 1/2"W x 17 1/2 - 20"D
Seat Ht Range	17 4/5" - 22 3/5"

Item No. 122201	Low back	\$578.00
Item No. 122202	High back, (Shown)	\$681.00

FRAME COLOR: BLACK

Available option: A

A. CORDE 4 FABRIC COLORS: CF10 - Black CF52 - Thalo CF78 - Parma Red CF56 - Medium Grey



MARYLAND CORRECTIONAL ENTERPRISES

For more information:
Contact Customer Service 410-540-5454
www.mce.md.gov